



# Google Watch Track/Thru Hole with M0659 Mounting Plate

*Installation Guide*



## Step-by-Step Instructions:

### STEP 01

Install M0659 circular Mounting Plate to the topside of the slotted table.



### STEP 02

Post will be visible beneath table.



### STEP 03

Insert space plate and knob.



### STEP 04

Turn and fasten knob against spacer plate.



# Google Watch Track/Thru Hole Mounting with M0659 Mounting Plate



## Step-by-Step Instructions:

### STEP 05

Remove adhesive from back of VHB. Install VHB to bottom of OEM charger.



### STEP 06

Remove adhesive from bottom of OEM charging base. Press and hold down watch OEM charging base for 10 seconds to secure VHB to circular Mounting Plate.



### STEP 07

Remove adhesive from back of CX Flex Watch Sensor Cable. Press and Hold CX Flex cable to back of watch for 10 seconds. Cable ending should exit the same direction as the watch crown.



### STEP 08

Set watch on charger.



### STEP 09

Rear view



### Incorrect Merchandising

**NOTE:**  
This photo shows **incorrect** installation.

**Remove** the watch stand.

