Universal Laptop with VHB Baseplate Kit



Installation Instructions

1.Fully extend legs on bracket by pressing buttons on bottom of laptop brackets.







2. Ensure that the ridges on the top of the bracket are positioned to the front. Next, center the laptop between the legs.





3. Insert left side of laptop in left leg and push toward center. Once left leg is flush to the bracket, push both legs in simultaneously toward the center.





4. Align tabs with square openings and place into adapter. Once positioned in adapter plate, slide bracket to the right to lock into place.





5. Align lock hole on bracket with lock, then press in lock to fully secure.



