

Freedom Micro II Samsung Flip 5/6 Speedbracket

Installation Guide



Kit Components

MICRO II SAMSUNG FLIP SPEEDBRACKET OPTIONS

SKU 165-01351



SKU 165-01386



Both of these brackets are compatible with the phone.

Additional Required Items (not included)

ALCOHOL WIPE



PHONE



FMII TOOL



Step-by-Step Instructions:

STEP 01

Clean the back of the phone with the alcohol wipe and let it dry. Peel off the adhesive liner on the bracket, unless this bracket is being used with a dummy phone.



STEP 02

Install bracket to phone, aligning bottom edge of phone with the bottom bracket arms. Press the adhesive firmly against the back of the phone for 10 seconds minimum.



STEP 03

Using the MTI tool, loosen the 2 screws on the back of the medallion. Push in left and right bracket arms snug to the phone.



STEP 04

Tighten both screws on the back of the medallion.



FINISH

Install SpeedBracket to riser and rotate into place, until a 'click' is heard. Wiggle the bracket to confirm the bracket is locked onto the puck. Then plug in charging cable.