



## INSTALLATION GUIDE FOR: Samsung Fold7 Bracket VHB Retrofit Kit

Step	Instruction
1	Remove old phone from shield bracket
2	Make sure the exterior surface of the phone is clean and dry.
3	Apply 454-00202 transfer tape to the phone's rear door surface.
4	If not already peeled, remove the white VHB liner from the 165-01352 Shield Bracket and remove liner from VHB Pad 454-00261 and mate together.
5	Remove transfer tape liner from 454-00261 VHB Pad.
6	Line up shield bracket to the Fold7, place onto the Fold7, close bracket arms securely and fasten the two screws.
7	Allow VHB and transfer tape to cure overnight to ensure best bond with the Fold7.

