

Adhesive Primer Kit

Installation Guide



Kit Components

ADHESIVE PRIMER



CLEANING WIPE



DESIRED VHB MOUNT



Step-by-Step Instructions:

STEP 01

Apply small drop of adhesive primer to surface.



STEP 02

Using polishing cloth, polish surface of phone where VHB will contact for 30 seconds.



STEP 03

Thoroughly wipe any remaining polish off phone surface with alcohol wipe. Allow to dry.



STEP 04

Apply VHB to phone, place pressure on VHB for 30 seconds.

