



## 3M ScotchBrite 7448 UltraFine Hand Pad – User Instructions

Purpose: In cases where it is preferred to showcase the phone without brackets and the phone surface is difficult for VHB or transfer tape to stick to, slightly abrading the phone surface with the 3M ScotchBrite 7448 hand pad is an option to improve adhesion.

### Important Considerations:

- This method creates a light-medium strength bond at best. For high-theft areas, brackets are still recommended.
- Abrading the phone's surface is a slight modification and may not be suitable for all situations.
- MTI cannot guarantee results or offer warranty on this solution.

### If you'd like to try this method:

1. Polish the phone's surface where the adhesive will be applied with the 3M Scotch-Brite™ 7448 Ultra Fine pad for about 45 seconds. Apply light to moderate pressure in a circular motion.
2. Clean the area with an alcohol wipe. You'll notice a change in how the alcohol reacts to the abraded surface.
3. Let the surface dry completely before applying the adhesive.
4. Apply firm pressure for a minimum of 10 seconds then allow the adhesive to cure for at least 2 hours.

**For phones with previously removed adhesives:** Repeat the above steps, as the abraded surface loses its surface energy over time.

**We're here to help!** If you have any questions or need further assistance, please don't hesitate to contact us.