


Required Tools




1. Default PIN 5555




On your first tap the pinpad will ask you to set a new PIN

2.




Type in your new PIN twice and hit enter

3.



You will see a new popup confirming your new PIN

4.



You can now activate and deactivate your card as needed.

- Activate your Versa Keycard at the beginning of your shift to be able to unlock locks
- If you have any questions please call MTI - 1-800-305-1043