




Riser




Watch Bracket



MTI Tool




Watch Stand Screws



Mounting Plate




Mounting Plate Screws



VHB


1 Align the 4 holes in the mounting plate with the holes in the bottom of the riser then use the MTI tool and 4 mounting plate screws to attach them together.




2 Set the stand onto the fixture, dropping the oval latch pieces into the slot.





3 Tighten down by using the MTI tool to tighten the 2 screws over the latch pieces.



4 Peel the clear liner off the back of the VHB adhesive pad and apply it to the top of the riser as shown. Do not peel the red liner from the top of the VHB.




- 5** Feed the charger through the back to rest on top of the VHB.



- 6** Fit the 2 watch brackets around the face of the watch, ensuring that the screw holes overlap.




 Some watch bands have a loop which interferes with the placement of the bottom watch bracket. See page 3 for steps to follow.

- 7** Set the watch with brackets on top of the charger and inside the stand, lining up the screw holes in the bracket with the hole on each side of the riser. Use the MTI tool to screw in the 2 watch stand screws on each side of the riser.



- 8** Connect the charger to power. Double-check that the watch is charging. If not, check the alignment of the charger to the back of the watch, re-installing the brackets as necessary.



- 1** Release the bottom watch band from the watch bezel. There is a release button on the back of the watch face.



- 2** Install the brackets on the watch and the bracketed watch on the stand.



- 3** Tuck in the bottom watch band into the stand.



- 4** Proceed with installation (Steps 5-8 above)

